


PROPER LOADING OF KT MAGAZINE

RECHARGEMENT CORRECT DU CHARGEUR DU KT



STEP 1: Slide the ball pusher towards the bottom of the magazine and turn to the right to place the guide roll pin in the locked position.

STEP 2: Press and hold the magazine ball stopper open while the paintballs are being loaded.

STEP 3: Load nine (9) Kingman Training 11mm Paintballs (.43 Cal.) into the magazine one at a time until the magazine is full.

STEP 4: Release the magazine ball stopper after the last ball has been loaded into the magazine.

STEP 5: Turn the ball pusher guide roll pin left to the un-locked position.

ETAPE 1: Faites glisser le ressort pousseur de billes vers le fond du chargeur et tournez vers la droite pour mettre goupille de sécurité en position verouillée.

ETAPE 2: Pressez et tenez le stoppeur de billes du chargeur ouvert pendant que les billes de paintball sont chargées.

ETAPE 3: Chargez neuf (9) billes de paintball Kingman Training de 11mm (.43 Cal.) dans le chargeur, une par une jusqu'à ce que le chargeur soit plein.

ETAPE 4: Relâchez le stoppeur de bille du chargeur après que la dernière bille ait été chargée dans le chargeur.

ETAPE 5: Tournez la goupille du pousseur de bille vers la gauche jusqu'à la position déverrouillée.